

Looking Through: Mapping Air


Cassini's Composite Infrared Spectrometer




Stephen J. Edberg
Cassini Program
October 29, 1999





The Cassini Spacecraft in the Solar Thermal Vacuum Chamber




CASSINI INTERPLANETARY TRAJECTORY



Cassini Orbital Tour at Saturn






JPL

Titan Northern Hemisphere



Titan Haze





Mimas



Enceladus



Tethys




Dione



Rhea



Hyperion




Iapetus




Phoebe




Very Large Array



CIRS Instrument on Cassini Remote Sensing Pallet



Spectrum of Sirius



CIRS

Description of Investigation

- Infrared Spectroscopy of Emission from Atmospheres, Rings, and Surfaces in
10 - 1400 cm^{-1} (1000 - 7 micron) Region
- Global Mapping in Saturn's and Titan's Atmospheres of The Three Dimensional and Temporal Variation of:
 - Temperatures
 - Gas Composition
 - Aerosols, Clouds
- Global Mapping of Saturn's Rings and Icy Satellite Surfaces for:
 - Composition and Thermal Properties
- Nadir and Limb Observational Modes. Limb Scanning Provides Scale Height Altitude Resolution.



CIRS Measurement Capabilities

Science Objectives

Saturn, Titan Atmospheres

Map Global Thermal Structure	<i>Dynamics, General Circulation</i>
Map Global Gas Composition	<i>Photochem, Dynamics, Evolution</i>
Map Global Information on Hazes & Clouds	<i>Haze Formation, Cloud Physics</i>
Determine Information on Non-equilib Processes	<i>Energetics</i>
Search for New Molecular Species	<i>Photochemistry, Evolution</i>

Titan Surface

Map/Global Surface Temperature	<i>Lower Atmosphere Dynamics</i>
--------------------------------	----------------------------------

Rings and Icy Satellites

Map Composition Thermal Characteristics	<i>Origin, Evolution, and Process</i>
Map Thermal Characteristics	



CIRS

Improvements Over Voyager IRIS

- Increased Altitude Resolution With Limb Sounding ($3 \Rightarrow 1 H_T$)
- Increased Sensitivity In Mid-IR
- Extended Spectral Coverage To Far-IR ($10\text{-}200\text{ cm}^{-1}$)
- Increased Spectral Resolution ($4.3 \Rightarrow 0.5\text{ cm}^{-1}$)
- Extended Spatial And Seasonal Coverage



CIRS

Top-Level Science Requirements

- Spectral Range: 1000 microns To 7.14 microns
 - Band 1 (FP1): 1000 - 16.7 microns ($10 - 600 \text{ cm}^{-1}$)
 - Band 2 (FP3): 16.7 - 9.1 microns ($600 - 1100 \text{ cm}^{-1}$)
 - Band 3 (FP4): 9.1 - 7.1 microns ($1100 - 1400 \text{ cm}^{-1}$)
- Spectral Resolution: $0.5\text{-}20 \text{ cm}^{-1}$, Commandable
- Fields Of View (Geometric, Centered Between FP3 & FP4, Non-overlapping)
 - FP1: 4.3 mrad (Circular)
 - FP3: **2.88 x 0.273 mrad (1 x 10 Array), 0.273 x 0.273 mrad Pixels**
 - FP4: **2.88 x 0.273 mrad (1 x 10 Array), 0.273 x 0.273 mrad Pixels**



CIRS

Instrument Concept

- The Composite Infrared Spectrometer (CIRS) Consists Of Combined Far-IR And Mid-IR Fourier Transform Spectrometers.
- The Two Spectrometers Share a 50 cm, F/6 Telescope and Mirror Transport Mechanism.
- Overall Spectral Coverage Is 10 to 1400 cm^{-1} (1000-7 microns) and Spectral Resolution is 0.5 to 20 cm^{-1} .
- The Far-IR Spectrometer is a Polarizing Interferometer with a Single Focal Plane (FP1):
 - **FP1: 10 - 600 cm^{-1}** , Two Thermopile Detectors
4.3 mrad Field-of-view.
 - FP3: 600 - 1100 cm^{-1} , 1 x 10 HgCdTe Array
0.273 mrad Field-of-View on Each Pixel.
 - FP4: 1100 - 1400 cm^{-1} , 1 x 10 HgCdTe Array
0.273 mrad Field-of-View on Each Pixel.

Pixels on Each Array are Selectable in Sets of 5 Output Channels.





CIRS

INSTRUMENT SUMMARY


<u>Telescope Diameter (cm)</u>	50.8		
<u>Interferometers:</u>	FIR	MIR	
Type:	POLARIZING	MICHELSON	
Spectral Range (cm ⁻¹)	10-600	600-1400	
Spectral Resolution (cm ⁻¹)	0.5-20	0.5-20	
Integration Time (sec)	50-2	50-2	
<u>Focal Planes:</u>	<u>FP1</u>	<u>FP3</u>	<u>FP4</u>
Spectral Range (cm ⁻¹)	10-600	600-110	1100-11400
Detectors:	Thermopile (2)	HgCdTe (1x10)	HgCdTe (1x10)
Pixel FOV (mrad)	4.3	0.273	0.273
Operating Temperature (K) (Stability +/- 0.1 K)	170	70,75,80,85	70,75,80,85




MICHELSON INTERFEROMETER




CIRS OPTICAL DESIGN




CIRS INSTRUMENT LAYOUT



CIRS CONCEPTUAL LAYOUT




CIRS FIELDS OF VIEW (FOV)




CASSINI

OPTICAL REMOTE SENSING FIELDS OF VIEW




PROJECTION ON SKY (ALONG -Y AXIS)




SPACECRAFT AXES




Composition of Interferogram




CIRS VIEWING GEOMETRY




TITAN SYNTHETIC NADIR SPECTRUM




TITAN SYNTHETIC NADIR SPECTRUM FOCAL PLANE 3



TITAN SYNTHETIC NADIR SPECTRUM FOCAL PLANE 4




CIRS FOCAL PLANE 3, 4 LIMB COVERAGE




CIRS

EXPECTED PERFORMANCE: TITAN LIMB VIEWING




CIRS FOCAL PLANE 1




CIRS


FOCAL PLANE 3, FOCAL PLANE 4



Blackbody Radiation



Diurnal Temperatures





CIRS Instrument Web Sites



<http://www701.gsfc.nasa.gov/cirs/inst.htm>

<http://www.jpl.nasa.gov/cassini/Science/MAPS/CIRS.html>






The future in Physics Software

 home

 oscillations and waves

 support

 contact us

 download



This CD ROM helps students understand some of the most difficult topics such as diffraction and interference and they enjoy using it too. " Charlie Burton - Carmel College.

Here are numerous software models ' to die for ' that show Doppler effect , damping ... A' Level Physics teachers will want to use these as demonstrations or class activities. The title offers something of a breakthrough in allowing you to get straight to the part you need without the usual garnish or multimedia frills." T.E.S Online 12th March 1999

Download a Windows 95/98/NT or Macintosh Trial version of Oscillations and Waves

Oscillations and Waves proved itself to be a big favorite with physics teachers at the BETT'99 exhibition in Olympia. Feedback from teachers indicates that our balance of clarity of design, a high level of interactivity and challenging tasks, notes and solutions is a recipe for success.

<http://www.fable.co.uk/index.htm>

